

POWERFLEX®

PART NUMBER

PFF26-121

DESCRIPTION

Lower Torque Mount Small Bush

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x Polyurethane Bush
- 1 x Stainless Steel Sleeve
- 1 x PTFE/Silicone Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Recommended Tools:

- Trolley Jack and Axle Stands
- 14mm & 17mm Sockets/Spanners
- Ratchet or Electric Impact Gun
- Torque Wrench

Fitting Instructions:

1. Raise the vehicle on either a lift or on axle stands to gain access to the inspection hole in the undertray and locate the torque mount.
2. Support the gearbox lightly with a transmission/trolley jack.
3. Undo the 17mm and two 14mm bolts to remove the original torque mount.
4. Securing the mount in a vice, remove the small end rubber bush including outer shell.
5. Clean any dirt from the bore of the mount and remove any sharp edges or burrs with a rounded file.
6. Press in the Powerflex bushes from either side of the mount.
7. Apply some of the supplied grease to the bore of the bush and press the sleeve in until flush with both end faces.
8. Refit the torque mount to the vehicle and secure using the 17mm and two 14mm bolts.
9. Tension all hardware to the manufacturer's recommended torque settings and lower the vehicle to finish.

