

POWERFLEX®

PART NUMBER

PFF60-1420

DESCRIPTION

UPPER ENGINE MOUNT INSERT

INSTALLATION GUIDE

Contents (parts per pack):

1 x Polyurethane Bush 1 x Cable-tie

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Unbolt and lift the coolant reservoir to expose the end of the engine mount. **DO NOT** attempt if the engine coolant is hot.
2. Open the insert and feed it into the voiding of the OE engine mount until it is fully wrapped around the rubber. Applying some washing up liquid may help the insert feed through.
3. Secure the supplied cable tie around the insert ensuring it sits in the moulded groove. Trim off the excess tail of cable tie.
4. Re-fit the coolant reservoir in place.
5. Tighten any loosened fasteners to manufacturer's torque settings.

