



PART NUMBER

**PFF60-524**

DESCRIPTION

**REAR LOWER ENGINE MOUNTING BUSH**

### INSTALLATION GUIDE

#### **Product description:**

This part replaces the original bush in bracket OE number: 8200277221 and fits 2.0L diesel models. PFF60-524 is designed to allow a controlled amount of engine movement through voids in the material. The kit includes polyurethane inserts that further reduce engine movement, perfect for track days or vehicles running increased power.



#### **Contents (parts per pack):**

- 2 x Polyurethane A bushes
- 2 x Polyurethane B inserts
- 1 x Stainless steel sleeve
- 1 x Grease

*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

*All fasteners must be tensioned to manufacturer's torque settings.*

#### **Fitting Instructions:**

1. Remove the original rubber bush from the engine mounting bracket. *Take note of the offset position of the original bush as the new bush will need to fit into the same orientation.*
2. Fit the polyurethane A bushes into the bracket with the part number PFF60-522A facing towards the smaller mounting point.
3. Apply some of the supplied grease to the bore of the bush and insert the sleeve.
4. To limit flexibility of the bush, fit the supplied B insert into the A bush.
5. Refit the bracket to the car and tension all hardware to manufacturers recommended torque settings.

**Part number here for  
correct orientation of bush**

