

INSTALLATION GUIDE

Product description:

This insert fits into the part with the OEM part numbers 112100035R, 112100057R, 112100039R.

Contents (parts per pack):

- 1 X Polyurethane A Bush
- 1 X Polyurethane B bush

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Fit the larger A part polyurethane insert into the upper right engine mounting bracket until it sits flush with the bracket. It may in some cases be easier to add some lubricant or washing up liquid to the insert to ease fitting.
2. Fit the legs of the smaller B part insert into the holes in the A part bush until the legs pop through both sections of the larger A part insert. The function of this part of the insert is to secure the larger A part bush into the bracket.

