

# POWERFLEX®

PART NUMBER

**PFF60-8020**

DESCRIPTION

**UPPER ENGINE TORQUE MOUNT**

## INSTALLATION GUIDE

### **Contents (parts per pack):**

- 1 x Pre-Assembled 60-8020BRKT
- 2 x Zinc Plated Mild Steel Washers
- 2 x Nylon Washers

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with a workshop manual.

It is recommended that:

- All work is to be carried out by a licensed technician.
- All safety precautions are adhered to.
- Wheel alignment is to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

### **Fitting Instructions:**

1. Remove the top engine cover and black plastic housing that covers the header tank and top of the washer bottle to gain access to the OE upper engine torque mount.
2. Undo the two 18mm bolts that secure the torque mount and remove from the vehicle.
3. Apply a small amount of the supplied PTFE/Silicone grease to the bore of each of the bushes and outside of the sleeves and insert both into their respective bushes.
4. Apply more of the remaining grease to the end faces of the bushes and place the nylon washers on the sleeve at the small bush end.
5. Fit the Powerflex mount to the car, inserting the small end of the bracket into its chassis location first and using the relevant bolt.
6. Slide the larger bush end into position in the engine mounted bracket, adding the larger washers top and bottom. Ensure that the holes of the two washers and sleeve line up correctly and then add the remaining bolt.
7. Finger tighten initially, and then tighten all hardware to the manufacturer's recommended specifications.
8. Re-fit the plastic engine covers and road test.

