



**PFF63-415**

**ROVER 25 GEAR LINKAGE REAR  
MOUNTING BUSH**

REMOVE THE TWO SMALL SLEEVES  
FROM THE ORIGINAL RUBBER BUSH.  
INSERT THESE INTO THE BORES OF THE  
POWERFLEX BUSH