

POWERFLEX®

PART NUMBER

PFF88-608

DESCRIPTION

Volvo Rear Trailing Arm To Hub Bushes

INSTALLATION GUIDE

Contents (parts per pack):

- 4 x Polyurethane Bushes
- 2 x Sleeves
- 2 x Powerflex Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the original bush from the arm, remembering to clean away any dirt and corrosion.
2. File away any sharp edges using a rounded file.
3. Insert the Polyurethane Bushes
4. Apply some of the supplied grease to the bore of the Polyurethane Bushes and insert the stainless steel sleeve
5. Refit the arm to the subframe, remembering to tighten all hardware to manufacturers recommended torque settings.



Figure 1



Facing
direction of
the car

Fitted Bushes

